




MASTER

MASTER LAT MACHINE 2080H 68-803045





Vartex AB
Batterivägen 14 43232 Varberg Sweden
<http://www.masterfitness.se/>



STEP 1




STEP 2



STEP 3



CABLE ASSEMBLY



13# Cable threading sequence: A→B→C→D→E→F→G→H→I→J

14# Cable threading sequence: D→K→L

PART LIST

NUMBER	DESCRIPTION	QUANTITY	NUMBER	DESCRIPTION	QUANTITY
1	Column	2	21	Hook	3
2L/2R	L/R Foot	1pair	22	Handle	2
3	Connecting Rod	2	23	Double output connection plate	1
4	Adjustable double pulley frame	1	24	HEX BOLT M16*100	19
5	Guide rod fixing bracket	2	25	HEX BOLT M16*105	2
6	Guide rod	2	26	countersunk bolt M10*20	4
7	Loading frame	1	27	HEX BOLT M10*45	13
8	Loading Rod	2	28	HEX BOLT M10*30	1
10R/L	L/R Combination pulley frame	1pair	29	WASHER 16	42
11	Lower fixed pulley frame	1	30	ARC WASHER 10	4
12	Active pulley frame	1	31	BIG WASHER 12	1
13	Cable A	1	32	WASHER 10	28
14	Cable B	1	33	LOCK NUT M16	21
15	Top weight stack+Selection Rod	1set	34	NUT M12	1
16	Weight stack (19pcs)	1set	35	LOCK NUT M10	14
17	Pull Pin	1	36	BIG WASHER 10	2
18	Buffer ring	2	37	countersunk bolt M10*25	2
19	Pulley φ90	12	38	Round pipe plug	2
20	Pulley φ110	1			